


Golf GPS, The 1<sup>st</sup> Elevation service

Golf A.R Service



User's Guide

Version 1.0



## Key Usages 1

### 1. Drag pin position

Drag pin flag at the pin position of the day.

### 2. Confirm current GPS position

Drag GPS position at the real position if necessary

### 3. Track the shot (5page)

Click the Shot button to count score and to measure the previous shot distance.

### 4. Save score (6page)

Rotate your phone on landscape, then scorecard will be displayed.

Enter your score by hole. Your score will be managed by m.phigolf.com.

Performance report will be supported.


### 5. Green View

Use cam view to measure the angle over a tree and Green Image View

### 6. Cam View Consider altitude difference

Use cam view for Elevation service

real yards = horizontal yards (+/-) altitude difference



# Key Usages 2

185-36 = 149 / 71

## 7. Green Reader(Ruler,Plumb bobing,Tilt)

### 1)Cam

Cam View Consider altitude difference  
-By obstacles to calculate the angle Like the right club

### 2) Ruler(Meter/Yard)

Users of location and can measure The Distance to the green

-Users must enter the height  
-Users in the standing position Phone Holes Green Holes,and overlapped the actual state measurements.



### 3)Plumb bobing

Plumb bob utility shows whether slice or Hook lies.

-Golf balls,golf balls actually clear the screenFocuses on the line to be green and a Pendulum Move back the direction of the judge

### 4)Green Tilt

Green tilt utility shows break direction and of The green.



# Selecting a Course

## Favorites

Favorites will appear after you play a round.

## Search

Enter a golfclub name more than 3 characters.

## Nearby


Display golfclubs that are near your location.  
If you do not see golfclubs near you,  
use other methods(Search, Browse).

## Browse

Search for golfclub by Country>States>Cities.  
Only USA, States is used

## Starting Hole / 9-Hole Only Rounds

Select your golfclub and Course. Once playing, scroll to your starting hole by pressing the arrows(next or previous hole symbols).




Touch tabs to select course selection methods

## Map View

### TouchPoint Positioning

Touch anywhere on the map to view distance to that point and from that point on the green.

### Track Shots

Press the shot icon  at any time to begin tracking the distance of a shot. This is for tracking distance and it counts the score. But the score should be modified on Scorecard view (Landscape the phone).

### Recommend Club - W5 (5Wood)

Phigolf Navi recommends the proper club number (according to setting my club)

### Green View



Green view displays green slope images or photos which are uploaded by other golfers or by Phigolf manager. Visit [m.phigolf.com](http://m.phigolf.com) for more.

### Draggable Tee/Green, GPS Markers

You can drag the marker if necessary



H 01

Hole Selector



Draggable GPS Position

